



Client Mode

Installation and firmware upgrade instruction

Connect your computer to ARMOR X1 with an Ethernet cable





Power on your ARMOR X1 by connecting the power adapter to it and plugging it to a wall outlet





Wait 5 minutes and check that the LED is static red















Wait for it to finish scanning







Wait for it to connect



This site can't be reached

zyxelsetup took too long to respond.


Try:


- · Checking the connection
- · Checking the proxy and the firewall
- Running Windows Network Diagnostics


ERR_CONNECTION_TIMED_OUT


Reload


If you see this, wait for 5 minutes, then press 'Reload' proceed to next step















Wait a few minutes





Wait for 2 minutes to restart

